# 骨传导蓝牙耳机



## 示意图

该耳机使用内置可充电电池,首次使用耳机必须给电池充满电。使 用中, 若语音"电量低"提示音, 表示电池电量低, 此时需要给耳 机充电。

将充电线连接到耳机的磁吸充电口,2小时左右即可充满。充电状 态指示灯长亮红灯, 充满电常亮蓝灯。

斥则无法充电甚至造成短路。

注意

充电

本产品的可充电电池必须妥善处理,以便回收利用。请 不要将电池放入火中, 以免引起爆炸。

磁吸充电有正负级对应, 相互吸附可正常充电, 相互排

#### 开关机

功能	操作	指示灯
开机	K++ "/\" " 2 E Fil	灯亮
关机	长按 " <b>心</b> "3-5 秒	灯灭

## 操作说明

功能	状态	操作	
音量十	蓝牙已连接	单击 " 十 "	
音量 —	血刀 し仕政	单击 " — "	
下—曲		长按 " 🛨 "1秒	
上一曲	播放音乐	长按 " — "1秒	
暂停播放			
恢复播放	暂停音乐	単击 " ひ "	
接或挂电话	来电时		
拒绝电话	本田町	长按 " <b>()</b> "2秒	
手机/蓝牙听筒切换	通话中	大按 0 249	
游戏/音乐模式切换	蓝牙已连接	4击 " ひ "	

## 使用说明

## 如何蓝牙配对 蓝牙配对: 在关机的状态下,长按" 🖒 "3-5秒,指示灯进入红蓝灯 闪烁状态, 此时即进入配对状态, 打开设备上的蓝牙 (手机/电脑) 搜索名称 "X500", 点击设备 "X500" 配对连接, 连接成功退 出,即可使用。 蓝牙/MP3模式切换: 3击 " 🖰 " 切换蓝牙和MP3(TF卡)模式。 强调: 开机自动默认蓝牙模式。

歌曲下载: 将原装充电数据线连接电脑和耳机,即可读取U盘,将 电脑歌曲复制到U盘。

MP3播放模式切换: 在MP3模式放歌时, 4击 "(')" 切换 随机 播放/顺序播放模式(带记忆功能)

#### AI智能语音控制

(手机需支持语音唤醒功能)

功能	状 态	操作
语音控制	蓝牙已连接	双击 ″ 🖒 "

说明: 在蓝牙连接状态中,双击电源键,听到提示音后,就可以语 音操控手机。

#### 灯效控制

功能	灯效状态	操作
灯效切换	常亮-慢呼吸-快闪-关闭灯效 (4种效果循环切换)	5击 ″ <b>心</b> ″

说明: 在蓝牙已连接或TF卡模式中。

#### 指示灯

充电中	常亮红灯
充电完成	常亮蓝灯
搜索配对	红蓝灯交替闪烁

### 产品参数

1	型号:	X500	蓝牙版本:	6.0
ł	充电:	X500 ≈2h 5V/150mA	电池容量:	190mAh
	输入:	5V/150mA	连接距离:	蓝牙10m

播放: ≈6h@60%音量 协议: HFP A2DP AVRCP

音乐格式支持: MP3, WAV, WMA, FLAC, M4A

#### 注意事项

#### 保养与清洁: 耳机不能长时间泡海水/盐水,使用后应用淡水冲洗擦干,不然充

- 电磁吸部分容易腐蚀。
- 如何长时间不使用,请至少一个月充满一次电。
- 请不要私自拆装产品上任何部件, 如发现产品有缺陷立即停止使 用, 联系销售方售后处理。
- 每次运动后请将耳机表面的水擦拭干净,特别是充电磁吸位置。 要及时处理干净, 防止汗水, 盐水腐蚀充电口, 影响产品寿命。
- 产品远离火源、热源、冷冻源、化学品、严禁暴力撞击拆装挤压
- 请使用输出5V1A及以内的充电头。



产品保修卡 该卡为产品保修凭证,请妥善保管

产品名称:	产品型号:
购买日期:	客戶名称:
B+≠++.	

### 产品维修记录

日期	不良现象	方案


## Bone Conduction Bluetooth Headphones

使用指南及保修说明 User Manual & Warranty Information



使用指南及保修说明 User Manual & Warranty Information

## Schematic diagram



#### Charge

The headphone uses a built-in rechargeable battery, the first use of the headphone must be fully charged to the battery. In use, if the voice promps "low battery", the battery is low, and you need to charge the headphone.

The charging cable should be connected to the headset's magnetic charging port, about 2 hours to fill. Charging status indicator is red light, full charge often blue light.

Note correspondence, mutual adsorption can be charged normally, and mutual repulsion will not charge or even cause a short circuit.

Magnetic charging has a positive and negative polarity

The rechargeable battery of this product must be properly disposed of for recycling. Please do not place the battery in a fire to avoid explosion.

#### Power On/Off

Function	Operation	Indicator
On	Press ' (¹) 'for 3-5s	Light is on
Off	Fless O 101 3-0s	Light is off

#### Operating instruction

Function	Status	Operation
Increase volume	Bluetooth connected	Click ' 🛨 '
Reduce volume	Bluetooth connected	Click ' — '
Next song		Press ' + ' for 1s
Previous song	Play music	Press ' - ' for 1s
Pause		
Resume	Pause music	Click ' 🖒 '
Answer the call / Hang up	Phone calls in	D. Adhyr o
Decline the call	Thore cans in	
Phone / Bluetooth earphone switch	On the phone	Press ' 🖒 ' for 2s
Switch between Game/Music mode	Bluetooth connected	4-click ' 🖒 '

#### Instruction

#### How to pair with Bluetooth

Bluetooth pairing: In the off state, press and hold ' () ' for 3 to 5 seconds, the indicator light will enter the red and blue light flashing state, and then enter the pairing state. Turn on the Bluetooth (mobile phone / computer) on the device and search for the device name " X500 ". Click the device " X500 " to pair and connect.

Bluetooth / MP3 mode switching: Triple-click '(')' free Switch bluetooth and MP3 mode,

Note: Bluetooth mode is default for boot.

Song download: Connect the magnetic charging cable to the computer and headphones, you can read the USB built-in memory In Bluetooth connected or TF card mode, Switching between card, and copy the songs from the computer to the USB.

MP3 playback mode switch: When playing audio in MP3 mode, 4-dick 'C' to switch between shuffle and sequential playback modes (with memory function)

#### Al intelligent voice control

## (Phone needs to support voice wake-up function)

unction	Status	Operation
oice control	Bluetooth connected	Double click ' 🖒 '

In the Bluetooth connection state, double-click the power button, and after hearing the prompt sound, you can voice control the

#### Light control

	Function	Light status	Operation
l	Light switching	Switching between 4 effects	5-click ' <b>じ</b> '

4 effects: always on, breathing light, fast blinking, and off.

#### Indicator

Chargi	ng Norm	ally on red light
Finished chargi	ng Norm	ally on blue light
Search for a mat	ch Red a	and blue lights flash alterna

#### Product parameter

Model: X500 Bluetooth: 6.0 Battery: 190mAh Charging time: ≈2h Input: 5V/150mA Distance: Bluetooth 10m

Operating time : ≈6h@60% Volume

Profile: HFP, A2DP, AVRCP

Music format support: MP3, WAV, WMA, FLAC, M4A

## Care and cleaning

- . The headphones should not soak in seawater/brine for a long time, as the magnetic charge part tends to decay. When going to the beach, it's better to protect the magnetic absorption point.
- If not used for a long time, please fully charge it at least once a
- . Do not disassemble any part of the product without permission. If you find that the earphone is defective, please stop using it.
- · Keep the product away from fire, heat, freezing, and chemicals. Do not immerse the earphone in water, and do not wipe it with chemicals such as aromatherapy water.
- Store in a cool, dry place. Do not expose the product to direct sunlight for a long time.
- Please use a charging head with an output of 5V1A or less.



#### Product warranty card This card is a product warranty certificate, please keep it properly

Product name: Product model: Purchase date: Clients name: Contact:

#### Product maintenance records

Date	Bad phenomenon	Solution
	Date	Date Bad phenomenon