骨传导蓝牙耳机

使用指南及保修说明
Operating instructions and Warranty description

① 指示灯　② 麦克风　③ 音量 "—" 键
④ 开关键　⑤ 音量 "＋" 键　⑥ 磁吸充电口

充电

该耳机使用内置可充电电池，首次使用耳机必须给电池充满电。使用者，若语音提示 "电量低" 时，表示电池电量低，此时需要给耳机充电。

将充电线连接到耳机的磁吸充电口，2小时左右即可充满充电状态指示灯红灯常亮，充满电常亮蓝灯

注意： 磁吸充电有正负极对应，相互吸附可正常充电，相互斥同无法充电甚至造成短路。

警告： 本产品的可充电电池必须妥善处理，以便回收利用。请不要将电池放入火中，以免引起爆炸。

操作说明

功能	操作	指示灯
开机	长按开关键3-5秒	灯亮
关机		灯灭

音乐播放

功能	耳机状态	操作
增加音量	播放音乐	单击+键
减少音量	播放音乐	单击-键
上一曲	播放音乐	长按1秒+键
下一曲	播放音乐	长按1秒+键
暂停播放	播放音乐	单击开机键
恢复播放	暂停播放	

接听电话

功能	耳机状态	操作
接挂电话	来电时	短按开机键接/挂
拒绝电话	来电时	长按2秒开机键挂断
音量控制	通话中	短按 "+" / "-" 键
手机/蓝牙听筒切换	通话中	长按1秒开机键

操作说明

如何蓝牙配对

蓝牙配对： 在关机的状态下，长按开机键2秒，指示灯进入红蓝闪烁状态，此时进入配对状态，打开设备上的蓝牙（手机/电脑）搜索设备名称 "X16" 点击设备 "X16" 配对，连接成功即可使用。

蓝牙/MP3模式切换： 双击开机键（多功能复合键）自由切换蓝牙和内存模式。

强调： 开机自动默认蓝牙模式状态。

歌曲下载（U盘名称：X16）： 将原装充电数据线连接电脑和耳机，即可读取U盘，将电脑歌曲复制到U盘。

TF卡播放模式切换： 在TF卡模式放取时，三击开机键切换 随机播放/顺序播放模式（带记忆功能）

温馨提示： 蓝牙耳机在开机后会自动搜索连接最新的设备。当蓝牙耳机与设备偏离10米(33英尺)的有效距离时，蓝牙耳机会与设备断开连接，只有在重新置于10米范围内时，它们才会重新连接如果蓝牙耳机与设备断开的时间过长，那么就需要单击蓝牙耳机上的多功能按键才能重新连接。

AI智能语音控制
（手机需支持语音唤醒功能）

功能	耳机状态	操作
语音控制	蓝牙已连接	长按开机键1秒松手

说明：在蓝牙连接状态中，长按开机键1秒松手后，会听到提示音后就可以语音操控手机，节约操作手机的时间，快捷智能

例如您可以直接操控耳机问：

说几点钟.........今天天气.........
导航去深圳世界之窗.........打电话给某某.........
打开播放云音乐.........播放刘德华的冰雨.........下一曲.........音量降低.........
打开美团.........打开喜马拉雅.........打开微信.........播放戏曲.........

智能运动，轻松好玩

指示灯

| 充电中	红灯常亮
充电完成	常亮蓝灯
搜索配对	红蓝灯交替闪烁
蓝牙音乐播放	蓝灯5秒慢闪

产品参数

* 版本：5、4　　　　* 电池：170mAh
* 充电：约2小时　　* 距离：蓝牙10米
* 输入：5V/130mA
* 播放：≈5小时×60%音量
* 协议：AVRCP_V1.6.2/HFP_V1.7.2/A2DP_V1.2
　蓝牙通信协议
* 支持格式：MP3、WAV、WMA、APE、FLAC、M4A

注意事项

保养与清洁：
● 耳机不能长时间泡海水/盐水，使用后应用淡水冲洗擦干充电磁吸部分容易腐蚀。
● 如果长时间不使用，请至少一个月充满一次电。
● 请不要私自拆装产品上任何部件，如发现产品有缺陷立即停止产品使用，联系销售方售后处理。
● 每次运动后请将耳机表面的水擦抹干净，特别是充电磁吸位置，要及时处理干净，防止汗水，盐水腐蚀充电口，影响产品寿命。
● 产品远离火源、热源、冷冻源、化学品，严禁暴力撞击拆装挤压产品。
● 请使用输出5V1A及以内的充电头。

Bone Conduction Bluetooth Headphone

Instructions for usage and warranty
Operating instructions and Warranty description

① Indicator light　② Microphone
③ Volume " — " button　④ Power button
⑤ Volume " ＋ " button　⑥ Charging port

Charge

The headphone uses a built-in rechargeable battery , the first use of the headphone must be fully charged to the battery .In use , if the voice promps "low battery", the battery is low, and you need to charge the headphone.

The charging cable should be connected to the headphone magnetic charging port , about 2 hours to be fully charged. The charging status： Red light (always on), full charge is always on the blue light.

Note : Magnetic charging has a positive and negative polarity correspondence, mutual adsorption can be charged normally, and mutual repulsion will not charge or even cause a short circuit.

Warning : The rechargeable battery of this product must be disposed of properly for recycling. Please do not put the battery into the fire ,so as not to cause an explosion .

Operating instruction

Function	Operation	Indicator
On	Press and hold Power button (around 3-5 seconds)	Light on
Off		Light off

Music Play

Function	Headphone status	Operation
Increase volume	Play music	Click " + "
Reduce volume	Play music	Click " - "
Previous song	Play music	Long press for 1s " - "
Next song	Play music	Long press for 1s " + "
Pause	Play music	Click the Power button
Resume	Pause	

Answer the phone

Function	Headphone status	Operation
Answer or hang up the call	Incoming call	Short press the power button
Decline the call	Incoming call	Long press the Power button for 2 second to hang up
volume control	During call	Click "+" / "-"
Phone/Bluetooth headset switch	During call	Long press and hold the Power button for 1 second

Operating instruction

How to pair with Bluetooth

Bluetooth pairing: In the off state, press and hold the power button for 2 seconds, the light into the red and blue flashing state, and then enter the pairing state, Turn on the Bluetooth (cell phone/computer) on the device and search for he device name " X16 ", click the device" X16 "to pair and connect.

Bluetooth / MP3 mode switching: Double click the power button (multi-function composite button) to freely switch between Bluetooth and memory mode.
　Emphasis: The power on automatically default Bluetooth mode status.

Song download(USB name:X16): Connect the original charging data cable to the computer and headset to read Take a USB flash drive and copy the computer song to the USB flash drive

TF card playback mode switch: When playing audio in TF card mode, triple-click 'Power' to switch between shuffle and sequential playback modes (with memory function)

Warm tip: Bluetooth headphone will automatically search for the latest device to connect after powering on. When the Bluetooth headphone and the device deviate from the effective distance of 10 meters (33 feet), the Bluetooth headphone will be disconnected from the device, and they will be reconnected only when they are placed within 10 meters again, if theBluetooth headphone is disconnected from the device for too long, then you need to click the multi-function button on the Bluetooth headphone to reconnect.

AI intelligent voice control
（Phone needs to support voice wake-up function）

Function	headphone status	Operation
Voice control	Bluetooth is connected	Long press for "Power" 1s to release

Note: In the Bluetooth connection status, press and hold "On/Off " for 1s to release your hand. After hearing the prompt, you can voice control the phone, saving time to operate the phone, fast and smart.
For example: You can directly control the earphone and ask: What time is it now......Today's weather......
Navigate to Taipei 101......Call someone ....
Smart exercise, easy and full of fun

Indicator

Charging	Red light (always on)
Charging completed	Blue light (always on)
Search for pairing	Flash in red and blue alternately
Bluetooth music playback	Blue light flashes once every 5 sec.

Product parameter

* Charging time: About 2 hours　　* Version: 5.4
* Distance: Bluetooth 10 meter　　* Input: 5V/130mA
* Battery: 170mAh
* Play: ≈5 hours@60% volume
* Agreement: AVRCP_V1.6.2/HFP_V1.7.2/A2DP_V1.2
　Bluetooth communication protocol
* Music format support: MP3, WAV, WMA, APE, FLAC, M4A

Maintenance and cleaning.

● The headphone can not soak seawater/salt water for a long time, they use fresh water to rinse and dry. Charging electromagnetic suction part is easy to corrode.
● If not used for a long time, please at least once a month full charge.
● Please do not disassemble any parts of the product, such as the discovery of product defects immediately stop using the product, and contact the seller after-sales service.
● After each campaign, please wipe the surface of the headphone water, especially the location of the filling electromagnetic suction, to deal with the cleaning in time to prevent sweat, and salt water corrosion charging port, affecting the life of the product.
● Keep the product away from fire ,heat,freezing sources, chemicals, violent impact disassembly and extrusion products are strictly prohibited .
● Please use a charging head with an output of 5V1A or less .